ENGLISH

user manual

Hydro

HYDRAULIC SWING GATE OPENER

quiklo® opening solutions

V04/2014

TECHNICAL FEATURES	QK-H400 QK-H400BC
Power	230Vac 50 / 60Hz
Current absorbed (motor) (A)	1,5
Power absorbed (W)	350
Capacitor (µF)	10
Protection level (IP)	55
Opening time (sec)	19
Stroke (mm)	380
Max. thrust (N)	9400
Working temp. (°C Min/Max)	-30/+70
Thermal cut-out (°C)	120
Working cycle (%)	80
Motor weight (kg)	10
Dimension A/B/C/D (mm)	380 / 465 / 453 / 1240
Max. leaf length (m)	6

	Installation limits per leaf *Limiti di'impiego per anta* Contraintes d'utilisation							
	2m	2,5m	3m	3,5m	4m	4,5m	5m	6m
QK-H400 / QK-H400BC	1100kg	1000kg	900kg	850kg	800kg	750kg	700kg	600kg

The values shown within the table above can be considerably reduced in windy areas.
I valori mostrati nella tabella sopra possono essere ridotti considerevolmente in zone ventose.
Les valeurs indiquées dans le tableau peuvent être considérablement réduits dans les zones venteuses.



Before installing the automation, you must check that the gate's shutter:

- The leaf turn freely in the hinges and without sticking in the ground
- It does not swing during its movement;
- is kept in axis by the special hinges;
- the leaves have the proper stoppages when opening and closing.

Quiko Italy Sas is liable only for products it manufactures and commercializes. Once automated, the gate becomes a machine and is therefore subjected to the rules of the " Machinery Directive". It is on the installer to verify its security. **WARNING:** Quiko Italy Sas is not liable for any damages to people, animals or things due to unauthorised modifications, alterations or betterments on its products by third parties.

GENERAL ADVICE

Install a gate's safety system that complies with current regulations. Choose short routes for cables and keep power cables separate from control ones. Install the control card in a waterproof box.
Please refer to current regulations when setting the gear motor's maximum torque.
We advice you to install an outdoor switch, in compliance with European standards on the issue of safety, to turn the electricity off when servicing the gate.
Check that each single installed device is efficient and effective.
Affix easily readable signs warning about the presence of a motorised gate.

USE

It is absolutely forbidden to use the device for any other purposes. Installed control board (which must have built-in electric friction), allows selecting the following functions:
automatic: one control impulse will open or close the gate;
semi-automatic: one control impulse will open or close the gate.
In case of blackout, act on the manual unlocking device and move manually the gate. Remember that this is an automatic device powered by electricity, consequently use with care. In particular, remember:

- not to touch the device with wet hands and/or wet or bare feet;
- to turn off electricity before opening the control box and/or actuator;
- not to pull the lead to pull the plug out;
- to put the gate in movement only when it is completely visible;
- to keep out of the gate's range of action if it is moving. Wait until it has stopped;
- not to let children or animals play near the gate;

not to let children use the remote control or other operating devices

INSTALLATION MATERIALS



Fig.1

1 – Bracket to wall Length 130 mm
2 – Bolt M12 X 30 with Nut
3 – Bolt M12 x 55 with Nut
4 – Bracket, to be weld to the leaf, length 65 mm
5 – Bushing
6 – Cylinder cover
7 – Manifold
8 – Tie rod cover
9 – Cup
10 – Release valve (for emergency manual operating)
11 – Fastening covers screws
12 – Breather screw
13 – Release valve key
14 – By pass valve (adjusting the piston thrust)

INSTALLATION

1- Arrange the electric cables installation and connection according to the below Fig.2



Fig. 2

Fig 2

2- Unloose and remove the two screws # 11 (fig 1) that fastens the tie rod cover to the cylinder.

Assemble:

- the wall brackets # 1 to cylinder bracket by means of the bolt and nut # 2
- the leaf bracket # 4 to cylinder rod by means of the bushing # 5 and bolt / nut # 3

3- Preassemble the cylinder to the gate according to the fig 3 and table 1



Fig 3

QK-H400 QK-H400BC					
α = 90°			α = 95°		
A (mm)	B (mm)		A (mm)	B (mm)	
	min	max		min	max
110	120	250	120	120	220
120	120	250	130	120	220
150	120	250	160	120	210
200	120	190	210	120	160
210	120	190	220	120	160
220	120	180	230	120	130
230	120	160	240	120	120

Table 1

4- Temporary fix the actuator to the wall and to the leaf (tack weld) and turn the leaf gate from the close position up to the max. open position (normally 95°) and check that the leaf turn freely in the hinges and without any swing during its movement.

5- Provide to complete the assembly of the actuator to the wall and to gate leaf.

6- Connect to the power supply cable 4x1,5 mm^2

the yellow-green wire = ground
grey or blue wire = common
black wire = phase
brown wire = phase

7- Proceed with the control board programming (see the CONTROL BOARD USER MANUAL)

Adjust the actuator thrust acting with the screwdriver on the by pass valves #14

Fig. 4

The opening and closing forces transmitted to the gate by the cylinder are regulated by adjusting two by pass valves.
The blue valve adjusts the opening pressure.
The red valve the closing pressure.

+ increase the actuator thrust

- decrease the actuator thrust

8- After installation take away the breather screw from the actuator Fig. 5



Fig. 5

MANUAL UNLOCKING

To release the opening and operate the leaves manually insert and turn the release key as shown within in the Fig. 6



Fig. 6



Risk Areas on Hinged Gates (figure 7)

LEGEND OF MECHANICAL RISKS CAUSED BY MOVEMENT

In accordance with the Regulation on Machinery, the following definitions are applicable:

- "Danger Zones:" any area inside and/or near a machine where the presence of a person is a risk to his/her health and safety.
- "Exposed Person:" any person located entirely or partially in a danger zone.



A. Impact **B.** Crushing **C.** Insulation

D. Conveyance **E.** Cutting **F.** Slicing

The installation must take a close risk examination to prevent crushing conveying cutting, grappling trapping so to guarantee a safe installation for persons animal and objects. Refer to the law applicable in the country where the installation takes place.

DECLARATION OF CONFORMITY

(OF THE MANUFACTURER)

Manufacturer: QUIKO ITALY SAS
Via Seccalegno, 19
36040 Sossano (VI)
Italia

hereby declares, under his liability, that the products:
QK-H400, QK-H400BC

are in compliance with the essential safety requirements of the regulations:

- ✓ Electromagnetic Compatibility Directive 2004/108/EC
- ✓ Low Voltage Directive 2006/95/EC
- ✓ Machinery Directive 2006/42/EC

and their amendments and modifications, and with the regulations set forth by the National Legislative Body of the country in which the machinery is destined for use.

Sossano, 17/03/2014

Managing Director
Luca Borinato

DECLARATION OF CONFORMITY

(OF THE INSTALLER)

The undersigned:

Address:

---

in charge of the set-up, declares that the product:

Gate type:

Location:

---

are in compliance with the essential safety requirements of the regulations:

✓Electro magnetic Compatibility Directive 2004/108/EC

✓Low Voltage Directive 2006/95/EC

✓Machinery Directive 2006/42/EC

and also declares that the related and/or specific national technical regulations have been followed:

- ✓ EN 12453/EN 12445 on Industrial, Commercial and Residential Gates and Doors – Safe Use of Motorized Doors – Requirements and Classification – Test Methods;
- ✓ EN 12604/ EN 12605 on Industrial, Commercial and Residential Gates and Doors – Mechanical Aspects – Requirements and Classification – Test Methods;
- ✓ CEI 64/8 Electrical Systems Using Nominal Tension Not Higher Than 1000V a.c. and 1500 V d.c.;
- ✓ EN 13241-1 (Industrial, commercial and garage doors and gates), conformity evaluation (6.3).

Notes:

Place and date: ……

QUIKO ITALY
Via Seccalegno, 19
36040 Sossano (VI) - Italy
Tel. +39 0444 785513
Fax +39 0444 782371
info@quiko.biz
www.quikoitaly.com

CE

The Manufacturer can technically improve the quality of its products without any prior notice.